

Vehicle Service Menu - Basic

For Mileage 10,000 / 30,000 / 50,000 / 70,000 / 90,000 / 110,000 / 130,000 / 150,000 / 170,000 / 190,000

Parts and Material Replacement

- Renew Engine Oil - Fully Synthetic (Shell / Mobil 1)
- Renew Engine Oil Filter
- Renew Drain Plug Washer
- Fill Windscreen Cleaner and Top up

Engine & Transmission

- Check Air Filter Condition, change if necessary
- Check Power Steering for leaks and fluid Level
- Check Drive Belt Condition
- Check Transmission Fluid Level and Condition
- Check Brake Fluid condition, change if necessary
- Check and Top up Engine Coolant
- Check and Top up Battery Water level

Chassis, Body & Electrical

- Check Front and Rear Suspensions
- Check Brake Pads Condition
- Check Brake Discs Condition
- Check Tyres Condition and Inflation Pressure
- Check Cabin Air-con Filter Condition
- Check Wiper Blades Condition
- Check Vehicle Lightings, Horn
- Check Battery Condition